

# K&M Wholesale Suppliers

## U0002 ENERGY CONTROLLER

### IMPORTANT NOTICE FOR OPERATION OF THE CONTROLLER

**NEVER EXCEED THE NUMBERED SETTING SHOWN ON THE CONTROLLER DIAL WHEN TURNING THE KNOB TO SET AND CONTROL THE POWER INPUT.** ALWAYS TURN CLOCKWISE TO SET CONTROLLER FROM 1-10 AND ANTICLOCKWISE TO DECREASE THE SETTING AND TURN OFF THE CONTROLLER..

**IF THE NATURAL CONTROL MAXIMUM SETTING IS EXCEEDED IT WILL DAMAGE THE CONTROL MECHANISM AND WILL NOT BE COVERED BY OUR WARRANTY!**

YOU WILL HEAR A CLICKING NOISE THAT INDICATED THAT THE CONTROL KNOB HAS EITHER REACHED THE MAXIMUM SETTING - CLOCKWISE MOTION OR HAS BEEN TURNED OFF- ANTI CLOCKWISE MOTION.

ALWAYS PLUG THE CONTROLLER INTO THE POWER SUPPLY AND THE KILN (CONTAINING TWO PIN CONNECTION) TO BE PLUGGED INTO TOP OF THE CONTROLLER.

WHEN RED LIGHT IS SHOWING THEN POWER IS ENTERING THE UNIT AND KILN AND WHEN LIGHT GOES OUT THE CONTROL MECHANISM IS IN USE.

TO TURN OFF THE POWER SUPPLY AND THUS TURN OFF THE KILN, ONE MAY SIMPLY, BY TURNING ANTI CLOCKWISE, RETURN THE CONTROL KNOB TO OFF **ALTHOUGH THE NUMBERED SETTING ON DIAL MAY INDICATE THE NUMBER 3.**

BE GENTLE WITH YOUR KILN & CONTROLLER WHICH WILL SERVE YOU WELL FOR MANY YEARS AND IF UNSURE CONCERNING THEIR USE, ALWAYS CONSULT YOUR SUPPLIER.